

# **755 UNIT** **STEEL BUSHINGS** **& COLLARS**

L BOOM PIVOT BUSHING

BED L BOOM  
PIVOT BUSHING

GREASE  
FITTING

GREASE  
SIDES OF  
BOOM

GREASE  
UPPER  
FOLD PIN

GREASE FOLD PIN

LOWER UNIT LOWER FOLD  
CYLINDER BUSHING

L BOOM FOLD  
BUSHING COLLAR

LOWER UNIT  
FRONT CYLINDER BUSHING

EXTENDABLE BOOM  
CYLINDER BUSHING

KING PIN  
EXTENSION  
BUSHING

GUIDE PLATE  
COLLARS

L BOOM  
UPPER FOLD  
CYLINDER  
BUSHING

GREASE  
EXTENSION

FRONT  
EXTENSION  
CYLINDER  
BUSHING

LOWER UNIT  
FOLD BUSHING

**CHANGE OIL FILTER EVERY 6 MONTHS**

